

Installation Guide

A step-by-step guide for DIY installation

Tools and fixings required

Pozidrive screwdriver	Electric drill
Measuring tape	Drill bits
Hacksaw	Screws
Bradawl	Suitable wall plugs
Spirit level	

Step 1: Sizing and fitting strike plates

Strike plates are oversized and will need to be cut down and fixed to each side of the wall / end panel. Using a level, position and fit each strike plate flush to the front of the opening.

Step 2: Sizing the tracks

You will be provided with two tracks. First measure the width of the top of your opening and use a set square to mark a straight line across the top track. Second measure the width of the floor of your opening and mark a corresponding line across the floor track. Cut the tracks using a fine tooth hack saw.

Step 3: Installing top and bottom tracks

Position the top track and drill and plug into the ceiling. Fix the top track using suitable screws and fixing (not supplied).

Before permanently fitting the floor track to the floor, fit the door into place and use a spirit level to ensure door is vertical.

Step 4: Insert the doors

Install the back door first and install by inserting in the top track on an angle. Straighten the door and lower the bottom wheels into the floor track grooves.

